Seznam kompatibilních objektivů							
Typ objektivu	Panasonic				Sigma	Leica	
	S5	S1	S1R	S1H	FP	SL601	SL2
Canon EF 50mm f/1.8 II	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-300mm f/4.0-5.6 IS II	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-55mm f/3.5-5.6 IS II	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 100mm f/2 USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 50mm f/1.4 USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/2	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 10-22mm f/3.5-4.5 USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 85mm f/1.8 USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 28mm f/1.8 USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 85mm f/1.2 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24mm f/1.4 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 200mm f/2.8 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-70mm f/2.8 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 14mm f/2.8 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 16-35mm f/2.8 L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/1.4L II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/4 L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 500mm f/4 L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 100-400mm f/4.5-5.6 L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/2.8 L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 600mm f/4L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-105mm f/4L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 16-35mm f/2.8 L III USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 135mm f/2 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/4 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 17-40mm f/4 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 180mm f/3.5 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 400mm f/5.6 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/2.8 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-70mm f/2.8 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 50mm f/1.2L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/1.4L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/2 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 85mm f/1.4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 500mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-70mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 16-35mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-300mm f/4-5.6 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 100-400mm f/4.5-5.6 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/2.8 L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 600mm f/4L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-105mm f/4L IS II USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 16-35mm f/2.8 L III USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 135mm f/2 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/4 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 17-40mm f/4 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 180mm f/3.5 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 400mm f/5.6 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/2.8 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-70mm f/2.8 L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 50mm f/1.2L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/1.4L USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 35mm f/2 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 17-85mm f/4-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-135mm f/3.5-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 15-85mm f/3.5-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 17-55mm f/2.8 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 85mm f/1.4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 500mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-70mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 16-35mm f/4 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-300mm f/4-5.6 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S

Canon EF 100-400mm f/4.5-5.6 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 70-200mm f/2.8 L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 200mm f/2L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 300mm f/4L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 200-400mm f/4L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-105mm f/4L IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 400mm f/4 Do IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 400mm f/2.8 L II	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 100mm f/2.8 L Macro IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 100mm f/2.8 Macro USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 60mm f/2.8 Macro USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 50mm f/1.8 STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 40mm f/2.8 STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 24mm f/2.8 STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 55-250mm f/4.0-5.6 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF 24-105mm f/3.5-5.6 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-135mm f/3.5-5.6 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-55mm f/3.5-5.6 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 17-85mm f/4-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-135mm f/3.5-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 15-85mm f/3.5-5.6 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 17-55mm f/2.8 IS USM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 10-18mm f/4.5-5.6 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 35mm f/2.8 IS STM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-200mm f/3.5-5.6 IS	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Canon EF-S 18-55mm f/3.5-5.6 IS	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 35mm F1.4 DG HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 30mm F1.4 DC HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 18-35mm F1.8 DC HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
Sigma 24-105mm f/4 DG OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 17-70mm F2.8-4 DC MACRO OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 50mm F1.4 DG HSM A014	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 18-200mm F3.5-6.3 DC MACRO OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 24-35mm F2.0 DG HSM A015	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 20mm F1.4 DG HSM A015	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 24mm F1.4 DG HSM A015	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 50-100mm F1.8 DC HSM A016	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 40mm F1.4 DG HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 105mm F1.4 DG HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 28mm F1.4 DG HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 85mm F1.4 DG HSM A	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 135mm F1.8 DG HSM A	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 50mm F1.4 EX DG HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 17-50mm F2.8 EX DC OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 150-600mm F5-6.3 DG OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 105mm F2.8 EX DG OS HSM MACRO	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 120-300mm f/2.8 DG OS HSM Sports	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 100-400mm F5-6.3 DG OS HSM	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S
SIGMA 70mm F2.8 DG ART	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S	AF-S